

# 19-Pin Socapex Wiring



(For unpowered, bi-amped loudspeakers)



Viewed from wiring side


Male

Female




NOTE POSITION OF ALIGNMENT KEYS

## 4-circuit (bi-amped loudspeaker) Socapex wiring



Not connected



Circuit 1

Circuit 2

Circuit 3

Circuit 4