

19-Pin Socapex Wiring



(For unpowered, passive loudspeakers)



Viewed from wiring side

Male

Female




NOTE POSITION OF ALIGNMENT KEYS


8-circuit (passive loudspeaker) Socapex wiring

- Pin 11
- Pin 10
- Pin 8
- Pin 9
- Pin 15
- Pin 16
- Pin 7
- Pin 6
- Pin 5
- Pin 4
- Pin 2
- Pin 3
- Pin 13
- Pin 18
- Pin 12
- Pin 1
- Pin 14
- Pin 17
- Pin 19

19-Pin Socapex



Not connected



Circuit 1 Circuit 2 Circuit 3 Circuit 4 Circuit 5 Circuit 6 Circuit 7 Circuit 8